

ZONBU: SAFETY GUIDE



THIS SAFETY GUIDE CONTAINS IMPORTANT SAFETY AND HANDLING INFORMATION FOR THE DEVICE. READ ALL SAFETY INFORMATION AND OPERATING INSTRUCTIONS BEFORE USING THE DEVICE TO AVOID INJURY.

WARNING: ELECTRICAL EQUIPMENT COULD BE HAZARDOUS IF MISUSED. OPERATION OF THIS DEVICE, OR SIMILAR PRODUCTS, MUST ALWAYS BE CONDUCTED OR SUPERVISED BY AN ADULT. DO NOT ALLOW CHILDREN TO ACCESS THE INTERIOR OF THE DEVICE OR HANDLE ANY CABLES. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK OR OTHER INJURY OR DAMAGE.

When setting up the Device, remember the following:

- Read all instructions carefully before you plug the Device into a power outlet.
- Keep these instructions handy for reference by you and others.
- Follow all instructions and warnings dealing with the Device.

General Safety Information

Do not drop the Device or subject it to other mechanical shocks. If you drop the Device or it is subject to another mechanical shock:

1. Save and close any open files, exit any open programs, and shut down the Device.
2. Disconnect the power adapter from the Device and from the electrical outlet.
3. Turn off any attached external devices, and disconnect them from their power sources and then from the Device.
4. Turn on the Device.

Operate the Device in the upright, vertical position to ensure proper ventilation. Placing the Device on its side will prevent ventilation, resulting in risk of overheating, fire or other injury or damage.

Always leave space around the Device and your power adapter. Do not use this equipment in a location where airflow is confined, such as a bookcase.

Operate the Device in a place where the temperature is always between 0 and 35 degrees C (32 to 95 degrees F). Store the Device in a place where the temperature is always between -20 and 45 degrees C (-4 to 113 degrees F). Keep the Device away from radiators and heat sources. Do not block cooling vents. Do not place the Device in a closed-in wall unit or on a bed, sofa or rug.

Do not place the Device or device accessory on any unstable surface. It could fall, thereby potentially causing serious injury to a person and serious damage to the Device or device accessory.

Take care when using the Device to route the power cord in a way that reduces the risk of injury to others, such as by tripping or choking.

Protect the Device from environmental hazards such as dirt, dust, food, liquids, temperature extremes and overexposure to sunlight.

Repair and Cleaning Safety Information

Do not attempt to service or make repairs to the Device yourself unless you are a trained service technician. No user-serviceable parts are inside. For service contact us at contact@zonbu.com.

Follow these general rules when cleaning the outside of the Device:

- Make sure the Device is unplugged.
- Use a soft, lint-free, dry cloth.
- Don't use aerosol sprays, alcohol, solvents or abrasives.

Power Safety Information

Use only the power adapter that came with the Device. Adapters for other electronic devices might look similar, but they could damage the Device.

When connecting or disconnecting your power adapter, always hold the power adapter by its sides. Keep fingers away from the metal part of the plug.

Never use a power adapter that shows signs of damage or excessive wear.

Before connecting the power adapter to the Device, make sure there are no foreign objects inside the power port.

The power adapter for the Device is a high-voltage component and should not be opened for any reason, even when the Device is off. If the power adapter needs service or repair, contact us at contact@zonbu.com.

Protect the Device and the power adapter from direct sunlight and rain or other moisture. Keep the Device and power adapter away from sources of liquids, such as drinks, wash basins, bathtubs, shower stalls, swimming pools and so on. Take care not to spill any food or liquid on the Device or its power adapter. If you do, then perform the following procedure only after you are certain that it is safe to do so. If the Device is connected to an electrical outlet, it is recommended that you turn off power at the circuit breaker before attempting to remove the power cables from the electrical outlet. Use the utmost caution when removing wet cables from a live power source.

1. Shut down the Device, disconnect the power adapter from the Device, and then disconnect the power adapter from the electrical outlet.
2. Turn off any attached external devices, and disconnect them from their power sources and then from the Device.
3. Ground yourself by touching one of the metal connectors on the back of the Device.
4. Place the Device right-side up to let air circulate all around it. Let the Device dry for at least 24 hours in a dry area at room temperature.

Depending on what you spilled and how much of it got into your equipment, you might have to send your equipment to us for service. Contact us at contact@zonbu.com for instructions. Any such service will not be covered by the Limited Warranty.

To help prevent electric shock, plug the power adapter and Device power cables into properly grounded power sources. If you use a power extension cable, use the appropriate type (2-prong or 3-prong) to mate with the power adapter power cable.

Before you connect the Device to an electrical outlet, check the power adapter voltage rating to ensure that the required voltage and frequency match the available power source. If you use an extension power cable with your power adapter, ensure that the total ampere rating of the products plugged into the extension power cable does not exceed the ampere rating of the extension power cable.

Do not push objects into air vents or openings of the Device. Doing so can cause fire or electrical shock by shorting out interior components.

To help avoid the potential hazard of electric shock, do not connect or disconnect any cables or perform maintenance on the Device during an electrical storm. Do not use the Device during an electrical storm.

When you move the Device between environments with very different temperature and/or humidity ranges, condensation could form on or within the Device. To avoid damaging the Device, allow sufficient time for the moisture to evaporate before using the Device.

Repetitive strain

When using the Device, take frequent breaks. If you experience any discomfort in your neck, shoulders, arms, wrists, hands (including thumbs and fingers), or other parts of the body when using the Device, cease use immediately. If discomfort persists, consult a physician.

Air Travel

When traveling, properly protect and package the Device to check it as baggage. You can put the Device through an X-ray security machine, but never put the Device through a metal detector.

Accessories

Please read and abide by the safety information provided for each accessory that you use in connection with the Device.

Trademarks

Zonbu, Zonbu.com, the Zonbu logo are, without limitation, either trademarks, service marks or registered trademarks of PConRails, LLC. Other product and company names included in this Agreement may be trademarks, service marks or registered trademarks of our suppliers or licensors. None of the foregoing may be copied, imitated, or used, in whole or in part, without our prior written permission or that of our suppliers or licensors.

ENERGY STAR® Compliance

The Device is certified to comply with Environmental Protection Agency (EPA) ENERGY STAR® requirements as configured when shipped by us.

ENERGY STAR® Emblem

The EPA's ENERGY STAR® program is a joint effort between the EPA and manufacturers to reduce air pollution by promoting energy-efficient products.

You can help reduce electricity usage and its side effects by turning off your product when it is not in use for extended periods of time, particularly at night and on weekends.

Recycling Information

We recommend that you dispose of your used computer hardware, monitors, printers and other peripherals in an environmentally sound manner. We provide a free take-back program to recycle your used Device responsibly. When you upgrade to a new Device or you're finished using your current one, simply return it to us and we'll dismantle the Device and recycle the components. Send the Device in your original packaging and we'll recycle that too. Contact us at contact@zonbu.com for detailed instructions.

ZONBU: WARRANTIES

AGREEMENT

These terms and conditions (this "Agreement") apply to your purchase of the PConRails device and/or related products and/or services and support sold in the US (collectively, the "Device") by PConRails. By accepting delivery of the Device, you accept and are bound to the terms and conditions of this Agreement. If you do not wish to be bound by this Agreement, you must notify us immediately and return the Device to us.

Warranties

The Device purchased from us comes with a three year limited warranty (the "Limited Warranty"). Provided you are a continuous subscriber of the Service in good standing, we will replace, refurbish or repair, at our option, the Device and/or any of its components if it is found to be defective. Simply contact us at contact@zonbu.com. The Limited Warranty does not apply to:

- Reasonable wear and tear of the Device
- Damage caused by accident, misuse, abuse, neglect or misapplication
- Any use of a compact flash card not provided by us
- Defects due to repairs or modifications made to the Device by anyone other than us or our authorized service representatives

Failure to observe all safety instructions contained in the user documentation will void the Limited Warranty and might lead to suspension or termination of the Service to the offender, legal action, or both.

LIMITATION OF LIABILITY

IN NO EVENT WILL ANY PCONRAILS PARTY BE LIABLE FOR ANY DAMAGES WHATSOEVER, INCLUDING WITHOUT LIMITATION ANY INDIRECT, CONSEQUENTIAL, SPECIAL, INCIDENTAL, OR PUNITIVE DAMAGES, LOSS OF PROFITS, BUSINESS INTERRUPTION, LOSS OF INFORMATION, PROGRAMS OR OTHER DATA, OR THE COST OF PROCUREMENT OF SUBSTITUTE SERVICES ARISING OUT OF, BASED ON, OR RESULTING FROM THIS AGREEMENT, YOUR USE OF THE DEVICE, OR ANY UNAUTHORIZED ACCESS TO OR ALTERATION OF YOUR DATA, EVEN IF SUCH PCONRAILS PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE EXCLUSION OF DAMAGES UNDER THIS SECTION L IS INDEPENDENT OF YOUR EXCLUSIVE REMEDY AND SURVIVES IN THE EVENT SUCH REMEDY FAILS OF ITS ESSENTIAL PURPOSE OR IS OTHERWISE DEEMED UNENFORCEABLE. THESE LIMITATIONS AND EXCLUSIONS APPLY WITHOUT REGARD TO WHETHER THE DAMAGES ARISE FROM (1) BREACH OF CONTRACT, (2) BREACH OF WARRANTY, (3) NEGLIGENCE, OR (4) ANY OTHER CAUSE OF ACTION, TO THE EXTENT SUCH EXCLUSION AND LIMITATIONS ARE NOT PROHIBITED BY APPLICABLE LAW. SOME JURISDICTIONS DO NOT ALLOW THE LIMITATION OR EXCLUSION OF CERTAIN WARRANTIES OR CONDITIONS, SO SOME OF THE ABOVE LIMITATIONS MIGHT NOT APPLY TO YOU.

IF YOU ARE DISSATISFIED WITH THE DEVICE, YOU DO NOT AGREE WITH ANY PART OF THIS CONTRACT, OR YOU HAVE ANY OTHER DISPUTE OR CLAIM WITH OR AGAINST ANY PCONRAILS PARTY WITH RESPECT TO THIS CONTRACT OR THE SERVICE, THEN YOUR SOLE AND EXCLUSIVE REMEDY IS TO (A) RETURN THE DEVICE PURSUANT TO THE LIMITED WARRANTY, OR (B) DISCONTINUE USING THE DEVICE AND THE SERVICE.

The PConRails Parties assume no responsibility for any damage or loss that could arise through the use of the Device or the Service. The PConRails Parties assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction or repair of the Device.

IF, NOTWITHSTANDING THE WAIVERS AND LIMITATIONS OF LIABILITY SET FORTH ABOVE, INCLUDING WITHOUT LIMITATION YOUR EXCLUSIVE REMEDY, WHICH LIMITATIONS YOU HEREBY ACKNOWLEDGE TO BE REASONABLE, PCONRAILS IS FOUND LIABLE TO YOU UNDER ANY THEORY OF LIABILITY, THE ENTIRE LIABILITY OF PCONRAILS TO YOU SHALL BE LIMITED TO THE AMOUNT YOU PAID FOR THE DEVICE (EXCLUSIVE OF ANY AMOUNT YOU PAID FOR USE OF THE SERVICE).